


Outer line (red on color prints) is fairing edge if resting on tops of stringers

1/48

Inner line is fairing edge if clearing stringers by scale distance



Scale bar segments are 1-in long. Adjust print scale to match.

